




CITY


60113




LEGO.com/city








1



1




2




3




4



1



2






2x




1x

3






4




5





2x

6




8




1x

7



2x



8





1x

9






1x





1x

10



1x


11







1x

12






13




14








1x

15






16




17





1x


18






1x


19



2x



20






1x

21







1x

22

1





2





1x

23






1x



2x

24





2x

25





26





2x



2x

27


1



2




2x







2x

28






29





2x


30





1x

31




1x



1x


32





1x

33






2x




2x

34



4x


35






4x

36




37





1x

38



2x



2x


39






2x

40




41





1x

42




2x



2x


43







1x

44



1x


45






2x

46






47





48







CITY



60076



60074




60073



60072

LEGO.COM/CITY



Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



: 00800 5346 5555

: 1-800-422-5346