



CITY

60114



LEGO.com/city

1



2







3




4










1







2





3






4






5




6





1x

7




8



2x

8





1x




1x

9





10






1x



1x

11








1x

12

1



2







1x

13

1



2







1x



1x


14





2x

15






2x



1x


16






1x

17







18








19







20







21






2x

22






23






24








1x

25






26





1x


27





2x


28





1x


29





2x


30





2x

31







1x



1x


32





2x


33







1x

34







35




1




2



3




4





1x



36





1x

37







1x



1x

38





1x

39





8x



2x



2x

40

1




2



3




2x





1x

41




1




2



3







CITY



60090



60091



60092



60093



60095

LEGO.COM/CITY



CITY



60079



60080



60078



60077

LEGO.COM/CITY



CITY



60076



60074



60073



60072

LEGO.COM/CITY



CITY



60051



60052



60050

LEGO.COM/CITY



2x
6054551



2x
4161326



2x
4160857



2x
6093053



1x
4649049



2x
366601



1x
303401



2x
611101



1x
9552



2x
302321



2x
4556153



2x
371021



1x
383221



1x
4298618



1x
9341



1x
4657964



1x
4648281



2x
307026



1x
4548180



1x
241226



1x
4218581



4x
302326



4x
243226



1x
6131571




2x
302126



1x
4285883



2x
6037746




1x
6092952




1x
4161266



1x
4161281



2x
4541984



2x
6037664



1x
4544720



3x
3000841



1x
4567333



3x
4217436



1x
4163306



1x
4650628



2x
4212446




1x
4537937



3x
4187743



1x
4165967



1x
6129986



3x
4278273



2x
4211383



2x
4657366



1x
6004990



1x
4211364



2x
6100030



1x
4211395



1x
4211385



8x
4529240



1x
6134910



1x
4502068



1x
6061595



Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



: 00800 5346 5555

: 1-800-422-5346